



Hickory Shaker (HS)

Wood Species: American Hickory

FaceFrame: Solid Wood

Door Style: Shaker Style

Box Construction: 1/2" Solid Plywood

Drawer Glide: Undermount Soft Close

Drawer Head: Solid Slab

Drawer Box: 3/4" Solid Wood Dovetail

Shelves: 3/4" Adjustable Shelves

Hinge: Soft Close 6 Way Adjustable
Concealed Hinge

Overlay: Full

Cabinet Interior: Natural Box, Shelves & Drawers

Cabinet Exterior: Natural

Important Note: These cabinets have unfinished sides and will require a skin or panel to conceal any exposed cabinet ends

18" H WALLS	ANGLED END	MICROWAVE	EASY REACH	UTILITY/PANTRY	ACCESSORIES	PANELS
SDW1218	WCA1236	MW3042	BER33	UC2490	UCD36	MTEP96
SDW1518	WCA1242	REFRIGERATOR	BER36	UC2496	ROT15	MVEPBH
SDW1818	BLIND CORNER	WR3315	LAZY SUSAN	UNIVERSAL OVEN	ROT18	WEP1542
30" H WALLS	WBC2730	WR3324	LS3312	UOC3384	ROT21	BEP3
W0930	WBC2736	WR3612	LS3612	UOC3390	ROT24	REP9624
W1230	WBC2742	WR3615	MICROWAVE	UOC3396	ROT24	WS1542
W1530	BRIDGE	WR3618	BMC27	VANITY BASE	ROT27	BS2435
W1830	W3012	WR3621	BMC30	VB12	ROT30	TS2496
W2130	W3312	WR3624	SINK BASE	VB15	ROT33	IS3696
W2430	W3612	SPICE DRAWERS	SB33	VB18	ROT36	SPW
W2730	W3015	WSC30	SB36	VANITY DRAWER	PG1530	PLYEB42
W3030	W3315	SINGLE DOOR	FSB36	VDB1221	PG1536	BBFBP4896
W3330	W3615	B12	DCSB36	VDB1521	PG1542	FILLERS
W3630	W3018	B15	TRAY BASE	VDB1821	PG1830	WF342
W3930	W3318	B18	TB09	VDB2121	PG1836	WF642
W4230	W3618	B21	SPICE DRAWERS	VDB2421	PG1842	WFF342
36" H WALLS	W3021	DOUBLE DOOR	BSD6	VANITY SINK	PG2130	WFF642
W0936	W3321	B24	BSR9	V2121	PG2136	BF3
W1236	W3621	B27	BSR12	V2421	PG2142	BF6
W1536	W3024	B30	18" W SPLIT PANTRY	V2721	PG2430	BFF3
W1836	W3324	B33	UCB1854	V3021	PG2436	BFF6
W2136	W3624	B36	SDW183024	V3621	PG2442	WF396
W2436	DECOR STACKERS	B39	SDW183624	V2421DL	PG3030	TF396
W2736	W1212PG	B42	SDW184224	V2421DR	PG3036	WFF396
W3036	W1512PG	B48	24" W SPLIT PANTRY	V3021DL	PG3042	TFF396
W3336	W1812PG	ANGLED END	UCB2454	V3021DR	PG3630	MOLDINGS
W3636	W2112PG	BA24	DDW243024	V3621DL	PG3636	CBLPN2
W3936	W2412PG	BLIND CORNER	DDW243624	V3621DR	PG3642	CBLPN3
W4236	W2712PG	BBC36	DDW244224	V4221DL	PGWDC30	TK8
42" H WALLS	W3012PG	DRAWERS	30" W SPLIT PANTRY	V4221DR	PGWDC36	LCM8
W0942	W3312PG	2DB24	UCB3054	V4821DD	PGWDC42	LVC
W1242	W3612PG	2DB27	DDW303024	V6021DD	W3DR18	BM8
W1542	CORNER	2DB30	DDW303624	VSDB60	W3DR24	LRM8
W1842	WDC2430	2DB33	DDW304224	ACCESSORIES	SGH	SM8
W2142	WDC2436	2DB36	36" W SPLIT PANTRY	AG2418	LWR3015	SHM8
W2442	WDC2442	DB12	UCB3654	FFS24	WINESC1515	OCS8
W2742	WDC42PG	DB15	DDW363024	FFS30	WINESC1818	ROPE8
W3042	EASY REACH	DB18	DDW363624	FFS36	PANELS	VA48
W3342	WER2430	DB21	DDW364224	FFS42	DP1230	DEC004
W3642	WER2436	DB24	UTILITY/PANTRY	PR3015	DP1236	SCDL
W3942	WER2442	DB30	UC1884	RHF30	DP1242	SAMPLES
W4242	MICROWAVE	DB36	UC1890	RHF36	DP2430	DD
ANGLED END	MW3030	CDB36	UC1896	TT2436	MTEP84	TOUCH-UP
WCA1230	MW3036		UC2484	UCD30	MTEP90	TUK